




# iCub Courses

## An introduction to iCub hardware and firmware

*For CAN-based iCubs, with some concepts about  
Ethernet-based iCubs.*

< [marco.randazzo@iit.it](mailto:marco.randazzo@iit.it) >

# Story of a command message






ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA

# iCub Hardware (CAN based)


## - Black iCub -



iCub CAN buses:

- 0 Head, Torso
- 1 Left arm
- 2 Right arm
- 3 Left leg
- 4 Right Leg
- 5 Left Hand
- 6 Right Hand
- 7-8-9 Skin (left arm, right arm, torso)

Each CAN bus can host up to 14 devices (motors boards/sensors). Address 0 is reserved to the cfw2.



The CFW-002 board is PC104+ standard expansion card directly connected to the PC104+ bus. The board has 10 CAN Bus 2.0B links, 2 IEEE 1394 (Firewire) high speed ports, one stereo microphone preamplifier and a single D-Class speaker output. The CFW-002 is designed to operate with the PC104+ CPU (Linux based). The device drivers are available for Linux (2.6.x kernel) which enable high bandwidth, low latency data stream towards and from the PC104+ card.

### Specifications

Power supply	3.3V, 5V and 12V
Communication	10x ESD-protected CAN Bus ports, 1Mbps. 2x Firewire 400Mbps IEEE-1394 compliant ports 33MHz PCI
Audio PA maximum power	920 mWatt over 8 ohm
Audio LNA SNR	74dB
Audio PGA regulation	7-step software controlled
Onboard RAM for CAN packets FIFOs	128Kbits
Microcontrollers	2X Infineon XC2287/XC2287M, up to 80 Mhz clock
OS support	Linux 2.6.X custom device driver
PC side connection	Standard PC104+ 33Mhz PCI connector
Operating conditions	0 to 50°C, humidity <85% without condensation
Dimensions [LxWxH]	96x116x13
Weight	72 g






ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA

# iCub Hardware (CAN based)

## - Black iCub -



iCub CAN buses:

- 0 Head, Torso
- 1 Left arm
- 2 Right arm
- 3 Left leg
- 4 Right Leg
- 5 Left Hand
- 6 Right Hand
- 7-8-9 Skin (left arm, right arm, torso)

Each CAN bus can host up to 14 devices (motors boards/sensors). Address 0 is reserved to the cfw2.

iCub is an assembly of 10 independent robots!






ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA

# iCub Hardware (Ethernet based)

- Blue iCub -






**EMS4**  
Ethernet Motor  
Supervisor

The EMS4 card is a 32-bit Arm Cortex-M4 embedded microcontroller based device designed for managing several communication channels in robotic applications. Its main function is to provide the bridges among two Ethernet 10/100 base-T high-speed link, two CAN-2.0B buses and six SPI-master buses. When connected to external motor-driver cards (i.e. 2FOC, BLL/BLP or MCP/MC4), the EMS4 embedded microcontroller provides enough computational power to directly manage up to four motor control-loops.


## Specifications

Power supply	Operating: 9.5Vcc to 58Vcc
Microcontroller	STM32F407VGT6, ARM Cortex M4 168MHz clock
Memory	256KB Flash ROM, 64KB SRAM and 64KB non-volatile EEPROM
Communications	Ethernet 10/100Mbps MAC with IEEE1588 capability. On board managed switch with dual 10T/100TX PHY ports, with auto-MDI/ MDI-X protocol
Expansion buses	2 independent CAN 2.0B buses / 6 (3x2 multiplexed) SPI Master buses
Special functions	3 axes accelerometer: 16bit output, full scale 2g, 4g or 8g 3 axes gyroscope: 16bit output, full scales 250dps, 500dps or 2000dps
Expansion I/O	7 general purpose terminals configurable as digital I/O, incremental encoder inputs, PWM outputs, analog inputs (6 channels), and analog outputs (2 channel)
Generated power supply	5Vcc $\pm 3\%$ , max. 450mA (CAN and SPI buses) / 3.3Vcc $\pm 3\%$ , max 200mA (CAN and SPI buses)
Tools	Programming and debugging tools from ST, Kail, GNU, Raisance, IAR and others. JTAG or USART download
Operating Conditions	0°C to 50°C, relative humidity < 85% (operating)
Dimensions [LxWxH]	58x42x11 mm (2.28x1.65x0.43 in)
Weight	17g





Revision History			
Revision	Date	Description	Short Description
1.0.0	20/10/2017	Architecture	
1.0.1	20/11/2018	Architecture	


 iIT - Istituto Italiano di Tecnologia Via Morego, 30 16163 - Genova		Project iCub 2.5	
Drawn marco maggioli		Created marco maggioli	Approved
Document O_Architecture Diagram1			Revision 3.3.0
Diagram Size A1	Date Thursday, October 26, 2017 3:28:34 PM		Sheet 1 of 1





ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA

# iCub Hardware (other CAN devices)




## FTSens 6 axis torque and force sensor with CAN Bus communication



The FTSens is capable of measuring 3 forces and 3 torques (in a Cartesian reference system) using a CAN bus line to transmit data in digital form. The sensor is based on semiconductor strain-gauge technology; the mechanical assembly contains all the signal conditioning electronics and a microcontroller for communication.

Specifications	
Power supply	5V±10%, current consumption max 100mA, provided from CAN Bus connector
Communication	CAN Bus 2.0B, 1Mbps
Channels	Six, 3 torques (Tx, Ty, Tz) and 3 forces (Fx, Fy, Fz)
Measure range	2000 N (Fx, Fy, Fz) 40 Nm (Tx, Ty) 30 Nm (Tz)
Resolution	0.25 N (Fx, Fy, Fz) 0.049 Nm (Tx, Ty) 0.037 Nm (Tz)
Output data	16 bit, 6 channels, up to 1K messages/sec
Microcontroller	dsPIC30F4013 16bit, 30MIPS, 48K Flash, 2K RAM, CAN, SPI
Alarms	CAN communication, memory, ADC and PGA
Digital filter	6 independent 5th order IIR
A/D Converter	16 bit, 250kops
Gain settings	Fixed analog gain
Offset correction	digital offset correction
Utilities	In field reprogramming, device configuration, graphical data analysis
Operating conditions	0 to 50°C, humidity <85% without condensation
Dimensions [ø, H]	45x18mm
Weight	122g

## Artificial Skin with MTB interface boards



Large Area tactile sensor based on capacitive technology. Up to 16 triangles with 12 sensors each (192 tarelts) interconnected on a flexible-pcb driven by a microcontroller board (MTB). The skin can be cut from the triangular panel and applied to any 3D surface.



Specifications	
Power supply	5V±10%, current consumption max 70mA
Communication	CAN Bus 2.0B 1Mbps
Microcontroller	dsPIC30F4011 16bit, 40MIPS, 48K Flash, 2K RAM, CAN, SPI
Resolution	8 bit
Bandwidth	From 25Hz up to 250Hz
Utilities	In field reprogramming, drive configuration, graphical data analysis
Operating conditions	0 to 50°C, humidity <85% without condensation
Dimensions [LxWxH]	MTB 25.5x17.4x7mm / Triangle side of 30mm, etched on a 0.22 mm flexible PCB
Weight	MTB 2g / Triangle 0.3g


## iCub CAN buses:

- 0 Head, Torso
- 1 Left arm
- 2 Right arm
- 3 Left leg
- 4 Right Leg
- 5 Left Hand
- 6 Right Hand
- 7-8-9 Skin (left arm, right arm, torso)



ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
12 111 010 111 111 111


# iCub Hardware (other CAN devices)



## iCub CAN buses:

- 0 Head, Torso
- 1 Left arm
- 2 Right arm
- 3 Left leg
- 4 Right Leg
- 5 Left Hand
- 6 Right Hand
- 7-8-9 Skin (left arm, right arm, torso)

## MC4-001 MCP-001 Quad DC Motor Driver



The MC4 board is a small motor controller capable of driving up to four brushed DC motors, using CAN bus communication for commands and control data exchange. This is complemented by a small power supply board (MCP).


Specifications	
Power supply	12 to 24V
Communication	CAN Bus 2.0B 1Mbps
Motor number, type	4 Brushed DC motors
Output current	1A continuous, 2A overcurrent protection
Microcontrollers	Freescale DSP56F807, 80MHz, 144KB Flash, 8KB SRAM, 2KB EEPROM
Incremental encoders	Magnetic and optical, with an index up to 16.000cpr (see LCORE, ROIE, ROIEL info sheet)
Absolute encoders	Magnetic, SPI communication (see AEA and AEA2 info sheet), Analog Hall effect sensors
Alarms	Overcurrent, I <sup>2</sup> T, emergency button, sensor feedback, CAN communication, current sensors
Velocity loop speed	Up to 1KHz
Position loop speed	Up to 1KHz
Utilities	In field reprogramming, the board can be either stacked or connected trough a cable
Operating conditions	0 to 50°C, humidity <85% without condensation
Dimensions [LWH]	MC4 80x30x9mm / MCP 80x30x11mm
Weight	MC4 20g / MCP 20g






ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA


# iCub Hardware (other CAN devices)




## MC4-001 MCP-001 Quad DC Motor Driver



The MC4 board is a small motor controller capable of driving up to four brushed DC motors, using CAN bus communication for commands and control data exchange. This is complemented by a small power supply board (MCP).




## Motor PWM (pulse width modulation)





ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA



iCub CAN buses:

- 0 Head, Torso
- 1 Left arm
- 2 Right arm
- 3 Left leg
- 4 Right Leg
- 5 Left Hand
- 6 Right Hand
- 7-8-9 Skin (left arm, right arm, torso)

# iCub Hardware (other CAN devices)

## BLL-001 BLP-001 Dual Brushless Motor Driver



This motor controller is made of two separate boards. The BLL contains the logic circuits, while the BLP includes the power drivers. The controller is capable of driving up to two 250W Brushless DC motors using CAN bus communication for command and control data exchange.


### Specifications

Power supply	18V to 48V
Communication	CAN Bus 2.0B 1Mbps
Motor number, type	Two Brushless DC
Output current	7A continuous, up to 25A I <sup>PT</sup> limited
Microcontrollers	Freescale DSP56F807, 80MHz, 144KB Flash, 8KB SRAM, 2KB EEPROM
Incremental encoders	Magnetic and optical, with index up to 16.000cpr (see LCORE, ROIE, ROIEL info sheet)
Absolute encoders	Magnetic, SPI communication compatible with AEA-001 and AEA-002 (see info sheet), Hall effect sensors
Alarms	Overcurrent, overvoltage, undervoltage, I <sup>2</sup> T, emergency button, sensor feedback, CAN communication, current sensors
Velocity loop speed	Up to 1KHz
Position loop speed	Up to 1KHz
Utilities	In field reprogramming, the board can be either stacked or connected trough a flat cable
Operating conditions	0 to 50°C, humidity <85% without condensation
Dimensions [LxWxH]	BLL 58x42x10mm / BLP 58x42x18mm
Weight	BLL 16g / BLP 47g



ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA


# iCub Hardware (other CAN devices)



brushless  
DC motors




6 steps \* 8 poles \* 100 (harmonic drive reduction)  
= 4800 ticks per revolution  
hall effect sensors can be used as an encoder!



High voltage  
(24-63V)

Low voltage  
(5V)



Hall Effect Sens 1

Hall Effect Sens 2

Hall Effect Sens 3

PHASE 1 - PWM

PHASE 2 - PWM

PHASE 3 - PWM

Electrical Deg. 0 60 120 180 240 300 360

Switch 1	1	1	1	0	0	0
Switch 2	0	0	1	1	1	0
Switch 3	1	0	0	0	1	1
Phase 1	+	+	0	-	-	0
Phase 2	-	0	+	+	0	-
Phase 3	0	-	-	0	+	+





ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
DI TECNOLOGIA

# The Controller Area Network (CAN-bus)

- Typical for automotive applications. Microcontroller can exchange messages without an host computer
- 4 wires (V+ GND, CANH, CANL (twisted pair))
- 1 Mbps
- Robust to no noise
- 11 bits of address. On iCub address is splitted in three groups of bits (xxx yyyy zzzz)


## Data frame [\[edit\]](#)

The data frame is the only frame for actual data transmission. There are two message formats:

- Base frame format: with 11 identifier bits
- Extended frame format: with 29 identifier bits

The CAN standard requires the implementation must accept the base frame format and may accept the extended frame format, but must tolerate the extended frame format.

## Base frame format [\[edit\]](#)



The frame format is as follows:

Field name	Length (bits)	Purpose
Start-of-frame	1	Denotes the start of frame transmission
Identifier (green)	11	A (unique) identifier for the data which also represents the message priority
Remote transmission request (RTR)	1	Dominant (0) (see Remote Frame below)
Identifier extension bit (IDE)	1	Declaring if 11 bit message ID or 29 bit message ID is used. Dominant (0) indicate 11 bit message ID while Recessive (1) indicate 29 bit message.
Reserved bit (r0)	1	Reserved bit (it must be set to dominant (0), but accepted as either dominant or recessive)
Data length code (DLC) (yellow)	4	Number of bytes of data (0–8 bytes) <sup>[a]</sup>
Data field (red)	0–64 (0-8 bytes)	Data to be transmitted (length in bytes dictated by DLC field)
CRC	15	Cyclic redundancy check
CRC delimiter	1	Must be recessive (1)
ACK slot	1	Transmitter sends recessive (1) and any receiver can assert a dominant (0)
ACK delimiter	1	Must be recessive (1)
End-of-frame (EOF)	7	Must be recessive (1)



# The CAN bus



USB to CAN converter:

Can be attached to the CANbus wires to log data, debug commands, program the boards.

Id=006F  
Class type: 0 (command) or 1 (status message)  
From: board 6  
To: board F

LEN=8

Net 0 | CAN USB331 | 1000 - CANreal

File CAN Send Help

Add/Delete ID Area

from to Add > 0x000 < 0x7FF

Net: 0 - CAN\_USB331 Start Trigger.. New CANreal

Baud rate: 1000 kBit/s Stop Log..

Clear

Exit

Frame-No	Trg	Absolute Time	RelTime	Description	Id	Alt	L	d1	d2	d3	d4	d5	d6	d7	d8	Test
292807		10:05:56.926...	0.688	006F	8	5B	03	02	19	50	01	02	00			P
292808		10:05:56.926...	0.048	006F	0											P
292809		10:05:56.926...	0.121	006F	8	5B	03	02	19	50	01	02	00			P
292810		10:05:56.927...	0.117	006F	8	5B	03	02	19	50	01	02	00			P
292811		10:05:56.927...	0.118	006F	8	5B	03	02	19	50	01	02	00			P
292812		10:05:56.927...	0.618	006F	8	5B	03	02	28	50	01	02	00			P
292813		10:05:56.927...	0.121	005F	8	5B	03	02	28	50	01	02	00			P
292814		10:05:56.928...	0.119	006F	8	5B	03	02	28	50	01	02	00			P
292815		10:05:56.928...	0.048	006F	0											P
292816		10:05:56.928...	0.690	006F	8	5B	03	02	19	50	01	02	00			P
292817		10:05:56.928...	0.049	006F	0											P
292818		10:05:56.928...	0.119	006F	8	5B	03	02	19	50	01	02	00			P
292819		10:05:56.929...	0.118	006F	8	5B	03	02	19	50	01	02	00			P
292820		10:05:56.929...	0.118	006F	8	5B	03	02	19	50	01	02	00			P
292821		10:05:56.929...	0.618	006F	8	5B	03	02	28	50	01	02	00			P
292822		10:05:56.929...	0.121	005F	8	5B	03	02	28	50	01	02	00			P
292823		10:05:56.930...	0.119	006F	8	5B	03	02	28	50	01	02	00			P
292824		10:05:56.930...	0.048	006F	0											P
292825		10:05:56.930...	0.690	006F	8	5B	03	02	19	50	01	02	00			P
292826		10:05:56.930...	0.048	006F	0											P
292827		10:05:56.930...	0.120	006F	8	5B	03	02	19	50	01	02	00			P
292828		10:05:56.931...	0.117	006F	8	5B	03	02	19	50	01	02	00			P
292829		10:05:56.931...	0.118	006F	8	5B	03	02	19	50	01	02	00			P
292830		10:05:56.931...	0.618	006F	8	5B	03	02	28	50	01	02	00			P
292831		10:05:56.931...	0.121	005F	8	5B	03	02	28	50	01	02	00			P
292832		10:05:56.932...	0.119	006F	8	5B	03	02	28	50	01	02	00			P
292833		10:05:56.932...	0.048	006F	0											P
292834		10:05:56.932...	0.693	006F	8	5B	03	02	19	50	01	02	00			P
292835		10:05:56.932...	0.047	006F	0											P
292836		10:05:56.932...	0.120	006F	8	5B	03	02	19	50	01	02	00			P
292837		10:05:56.933...	0.118	006F	8	5B	03	02	19	50	01	02	00			P
292838		10:05:56.933...	0.118	006F	8	5B	03	02	19	50	01	02	00			P
292839		10:05:56.933...	0.616	006F	8	5B	03	02	28	50	01	02	00			P
292840		10:05:56.933...	0.121	005F	8	5B	03	02	28	50	01	02	00			P
292841		10:05:56.934...	0.119	006F	8	5B	03	02	28	50	01	02	00			P
292842		10:05:56.934...	0.048	006F	0											P
292843		10:05:56.934...	0.691	006F	8	5B	03	02	19	50	01	02	00			P
292844		10:05:56.934...	0.048	006F	0											P
292845		10:05:56.934...	0.120	006F	8	5B	03	02	19	50	01	02	00			P
292846		10:05:56.935...	0.117	006F	8	5B	03	02	19	50	01	02	00			P
292847		10:05:56.935...	0.119	006F	8	5B	03	02	19	50	01	02	00			P
292848		10:05:56.935...	0.617	006F	8	5B	03	02	28	50	01	02	00			P
292849		10:05:56.935...	0.121	005F	8	5B	03	02	28	50	01	02	00			P
292850		10:05:56.936...	0.119	006F	8	5B	03	02	28	50	01	02	00			P
292851		10:05:56.936...	0.048	006F	0											P

8 bytes of data: 5B 03 02 28 50 01 02 00  
5B is the command  
The other 7 bytes are parameters

Send ID: 29-84 RTR Len: 0 Data\$ Clear

Fill:1000(100.0%) Bus:-Lost:255 STOPPED

EN 09:57 04/07/2014



ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# The iCub CAN messages

Seven types of class messages:

- Class 0 (000 <XXXX> <YYYY>) command messages for motor control boards (e.g. position move) set/get messages (e.g. set pid)
- Class 1 (001 <XXXX> <TTTT>) motor control messages messages broadcasted from a specific board to all the other devices (e.g. joint position, velocity, pwm)
- Class 2 (010 <XXXX> <YYYY>) command message for a sensor board (e.g. set period FT sensor)
- Class 3 (011 <XXXX> <TTTT>) broadcast message from a sensor board (e.g. force torque data)
- Class 7 (111 <XXXX> <YYYY>) canLoader message (e.g. firmware update)

<XXXX> source address (0-15)

<YYYY> destination address ID (0-15)

<TTTT> type of message (0-15)

Examples:

000 0000 0101 - a command from the user (0000) to board 5 (0101)

1 0101 0000 - the answer of command from board 5 (0100) to the user (0000)

2 0101 0100 - a broadcasted message of the current consumption 4 (0100) from board 5 (0101)



ISTITUTO ITALIANO  
DI TECNOLOGIA

DI TECNOLOGIA  
INTELLIGENTE

# The iCub CAN messages

```
// command messages of class ICUBCANPROTO_CLASS POLLING MOTORCONTROL  
/*****
```

```
#define ICUBCANPROTO_POL_MC_CMD_NO_MESSAGE 0  
#define ICUBCANPROTO_POL_MC_CMD_CONTROLLER_RUN 1  
#define ICUBCANPROTO_POL_MC_CMD_CONTROLLER_IDLE 2  
#define ICUBCANPROTO_POL_MC_CMD_TOGGLE_VERBOSE 3  
#define ICUBCANPROTO_POL_MC_CMD_CALIBRATE_ENCODER 4  
#define ICUBCANPROTO_POL_MC_CMD_ENABLE_PWM_PAD 5  
#define ICUBCANPROTO_POL_MC_CMD_DISABLE_PWM_PAD 6  
#define ICUBCANPROTO_POL_MC_CMD_GET_CONTROL_MODE 7  
#define ICUBCANPROTO_POL_MC_CMD_MOTION_DONE 8  
#define ICUBCANPROTO_POL_MC_CMD_SET_CONTROL_MODE 9  
#define ICUBCANPROTO_POL_MC_CMD_WRITE_FLASH_MEM 10  
#define ICUBCANPROTO_POL_MC_CMD_READ_FLASH_MEM 11  
#define ICUBCANPROTO_POL_MC_CMD_GET_ADDITIONAL_INFO 12  
#define ICUBCANPROTO_POL_MC_CMD_SET_ADDITIONAL_INFO 13  
#define ICUBCANPROTO_POL_MC_CMD_SET_SPEED_ESTIM_SHIFT 14  
#define ICUBCANPROTO_POL_MC_CMD_SET_DEBUG_PARAM 18  
#define ICUBCANPROTO_POL_MC_CMD_GET_DEBUG_PARAM 19  
#define ICUBCANPROTO_POL_MC_CMD_GET_ENCODER_POSITION 20  
#define ICUBCANPROTO_POL_MC_CMD_SET_DESIRED_POSITION 21  
#define ICUBCANPROTO_POL_MC_CMD_GET_DESIRED_POSITION 22  
#define ICUBCANPROTO_POL_MC_CMD_SET_DESIRED_VELOCITY 23  
#define ICUBCANPROTO_POL_MC_CMD_GET_DESIRED_VELOCITY 24  
#define ICUBCANPROTO_POL_MC_CMD_SET_DESIRED_ACCELER 25  
#define ICUBCANPROTO_POL_MC_CMD_GET_DESIRED_ACCELER 26  
#define ICUBCANPROTO_POL_MC_CMD_POSITION_MOVE 27  
#define ICUBCANPROTO_POL_MC_CMD_VELOCITY_MOVE 28  
#define ICUBCANPROTO_POL_MC_CMD_SET_ENCODER_POSITION 29  
#define ICUBCANPROTO_POL_MC_CMD_SET_P_GAIN 30  
#define ICUBCANPROTO_POL_MC_CMD_GET_P_GAIN 31  
#define ICUBCANPROTO_POL_MC_CMD_SET_D_GAIN 32  
#define ICUBCANPROTO_POL_MC_CMD_GET_D_GAIN 33  
#define ICUBCANPROTO_POL_MC_CMD_SET_I_GAIN 34  
#define ICUBCANPROTO_POL_MC_CMD_GET_I_GAIN 35  
#define ICUBCANPROTO_POL_MC_CMD_SET_ILIM_GAIN 36  
#define ICUBCANPROTO_POL_MC_CMD_GET_ILIM_GAIN 37  
#define ICUBCANPROTO_POL_MC_CMD_SET_OFFSET 38  
#define ICUBCANPROTO_POL_MC_CMD_GET_OFFSET 39  
#define ICUBCANPROTO_POL_MC_CMD_SET_SCALE 40  
#define ICUBCANPROTO_POL_MC_CMD_GET_SCALE 41  
#define ICUBCANPROTO_POL_MC_CMD_SET_TLIM 42  
#define ICUBCANPROTO_POL_MC_CMD_GET_TLIM 43  
#define ICUBCANPROTO_POL_MC_CMD_SET_DESIRED_TORQUE 44  
#define ICUBCANPROTO_POL_MC_CMD_GET_DESIRED_TORQUE 45  
#define ICUBCANPROTO_POL_MC_CMD_STOP_TRAJECTORY 46  
#define ICUBCANPROTO_POL_MC_CMD_SET_BOARD_ID 50  
#define ICUBCANPROTO_POL_MC_CMD_GET_BOARD_ID 51  
#define ICUBCANPROTO_POL_MC_CMD_SET_TORQUE_SOURCE 52
```

```
#define ICUBCANPROTO_POL_MC_CMD_GET_PID_ERROR 55  
#define ICUBCANPROTO_POL_MC_CMD_GET_CALIBRATION_STATUS 56  
#define ICUBCANPROTO_POL_MC_CMD_GET_ERROR_STATUS 60  
#define ICUBCANPROTO_POL_MC_CMD_GET_ENCODER_VELOCITY 61  
#define ICUBCANPROTO_POL_MC_CMD_SET_COMMAND_POSITION 62  
#define ICUBCANPROTO_POL_MC_CMD_GET_PID_OUTPUT 63  
#define ICUBCANPROTO_POL_MC_CMD_SET_MIN_POSITION 64  
#define ICUBCANPROTO_POL_MC_CMD_GET_MIN_POSITION 65  
#define ICUBCANPROTO_POL_MC_CMD_SET_MAX_POSITION 66  
#define ICUBCANPROTO_POL_MC_CMD_GET_MAX_POSITION 67  
#define ICUBCANPROTO_POL_MC_CMD_SET_MAX_VELOCITY 68  
#define ICUBCANPROTO_POL_MC_CMD_GET_MAX_VELOCITY 69  
#define ICUBCANPROTO_POL_MC_CMD_GET_ACTIVE_ENCODER_POSITION 70  
#define ICUBCANPROTO_POL_MC_CMD_SET_ACTIVE_ENCODER_POSITION 71  
#define ICUBCANPROTO_POL_MC_CMD_SET_CURRENT_LIMIT 72  
#define ICUBCANPROTO_POL_MC_CMD_SET_BCAST_POLICY 73  
#define ICUBCANPROTO_POL_MC_CMD_SET_VEL_SHIFT 74  
#define ICUBCANPROTO_POL_MC_CMD_SET_OFFSET_ABS_ENCODER 75  
#define ICUBCANPROTO_POL_MC_CMD_GET_OFFSET_ABS_ENCODER 76  
#define ICUBCANPROTO_POL_MC_CMD_SET_SMOOTH_PID 77  
#define ICUBCANPROTO_POL_MC_CMD_SET_TORQUE_PID 78  
#define ICUBCANPROTO_POL_MC_CMD_GET_TORQUE_PID 79  
#define ICUBCANPROTO_POL_MC_CMD_SET_TORQUE_PIDLIMITS 80  
#define ICUBCANPROTO_POL_MC_CMD_GET_TORQUE_PIDLIMITS 81  
#define ICUBCANPROTO_POL_MC_CMD_SET_POS_PID 82  
#define ICUBCANPROTO_POL_MC_CMD_GET_POS_PID 83  
#define ICUBCANPROTO_POL_MC_CMD_SET_POS_PIDLIMITS 84  
#define ICUBCANPROTO_POL_MC_CMD_GET_POS_PIDLIMITS 85  
#define ICUBCANPROTO_POL_MC_CMD_SET_VEL_TIMEOUT 86  
#define ICUBCANPROTO_POL_MC_CMD_SET_IMPEDANCE_PARAMS 87  
#define ICUBCANPROTO_POL_MC_CMD_GET_IMPEDANCE_PARAMS 88  
#define ICUBCANPROTO_POL_MC_CMD_SET_IMPEDANCE_OFFSET 89  
#define ICUBCANPROTO_POL_MC_CMD_GET_IMPEDANCE_OFFSET 90  
#define ICUBCANPROTO_POL_MC_CMD_GET_FIRMWARE_VERSION 91  
#define ICUBCANPROTO_POL_MC_CMD_SET_OPTICAL_ENC_RATIO 92  
#define ICUBCANPROTO_POL_MC_CMD_SET_POS_STICTION_PARAMS 93  
#define ICUBCANPROTO_POL_MC_CMD_GET_POS_STICTION_PARAMS 94  
#define ICUBCANPROTO_POL_MC_CMD_SET_TORQUE_STICTION_PARAMS 95  
#define ICUBCANPROTO_POL_MC_CMD_GET_TORQUE_STICTION_PARAMS 96  
#define ICUBCANPROTO_POL_MC_CMD_SET_BACKEMF_PARAMS 97  
#define ICUBCANPROTO_POL_MC_CMD_GET_BACKEMF_PARAMS 98  
#define ICUBCANPROTO_POL_MC_CMD_SET_MODEL_PARAMS 99  
#define ICUBCANPROTO_POL_MC_CMD_GET_MODEL_PARAMS 100  
#define ICUBCANPROTO_POL_MC_CMD_SET_CURRENT_PID 101  
#define ICUBCANPROTO_POL_MC_CMD_GET_CURRENT_PID 102  
#define ICUBCANPROTO_POL_MC_CMD_SET_CURRENT_PIDLIMITS 103  
#define ICUBCANPROTO_POL_MC_CMD_GET_CURRENT_PIDLIMITS 104  
#define ICUBCANPROTO_POL_MC_CMD_SET_VELOCITY_PID 105  
#define ICUBCANPROTO_POL_MC_CMD_GET_VELOCITY_PID 106  
#define ICUBCANPROTO_POL_MC_CMD_SET_VELOCITY_PIDLIMITS 107  
#define ICUBCANPROTO_POL_MC_CMD_GET_VELOCITY_PIDLIMITS 108  
#define ICUBCANPROTO_POL_MC_CMD_SET_DESIRED_CURRENT 109  
#define ICUBCANPROTO_POL_MC_CMD_GET_DESIRED_CURRENT 110  
#define ICUBCANPROTO_POL_MC_CMD_SET_PERIODIC_MSG_CONTENTS 111  
#define ICUBCANPROTO_POL_MC_CMD_SET_I2T_PARAMS 112  
#define ICUBCANPROTO_POL_MC_CMD_GET_I2T_PARAMS 113  
#define ICUBCANPROTO_POL_MC_CMD_SET_OPENLOOP_PARAMS 114  
#define ICUBCANPROTO_POL_MC_CMD_GET_OPENLOOP_PARAMS 115  
#define ICUBCANPROTO_POL_MC_CMD_SET_INTERACTION_MODE 116  
#define ICUBCANPROTO_POL_MC_CMD_GET_INTERACTION_MODE 117  
#define ICUBCANPROTO_POL_MC_CMD_MAXNUM  
ICUBCANPROTO_POL_MC_CMD_GET_INTERACTION_MODE + 1
```



ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# The iCub CAN messages

```

/*****
/
// messages of class 1: ICUBCANPROTO_CLASS_PERIODIC_MOTORCONTROL
/*****
#define ICUBCANPROTO_PER_MC_MSG_2FOC 0
#define ICUBCANPROTO_PER_MC_MSG_POSITION 1
#define ICUBCANPROTO_PER_MC_MSG_PID_VAL 2
#define ICUBCANPROTO_PER_MC_MSG_STATUS 3
#define ICUBCANPROTO_PER_MC_MSG_CURRENT 4
#define ICUBCANPROTO_PER_MC_MSG_OVERFLOW 5
#define ICUBCANPROTO_PER_MC_MSG_PRINT 6
#define ICUBCANPROTO_PER_MC_MSG_VELOCITY 7
#define ICUBCANPROTO_PER_MC_MSG_PID_ERROR 8
#define ICUBCANPROTO_PER_MC_MSG_DEBUG 9
#define ICUBCANPROTO_PER_MC_MSG_MOTOR_POSITION 10
#define ICUBCANPROTO_PER_MC_MSG_MOTOR_SPEED 11
#define ICUBCANPROTO_PER_MC_MSG_ADDITIONAL_STATUS 12
#define ICUBCANPROTO_PER_MC_MSG_EMSTO2FOC_DESIRED_CURRENT 15

/*****
/
// command messages of class 2: ICUBCANPROTO_CLASS_POLLING_ANALOGSENSOR
/*****
#define ICUBCANPROTO_POL_AS_CMD_NONE 0x0
#define ICUBCANPROTO_POL_AS_CMD_SET_IIR 0x1 // select IIR filters parameters
#define ICUBCANPROTO_POL_AS_CMD_SET_MATRIX_RC 0x3 // Set SG to TF trasformation matrix
#define ICUBCANPROTO_POL_AS_CMD_SET_CH_DAC 0x4 // set DAC for channel x
#define ICUBCANPROTO_POL_AS_CMD_SELECT_ACTIVE_CH 0x5 // set active channels (activation mask) only active channels are
#define ICUBCANPROTO_POL_AS_CMD_CALIBRATE_OFFSET 0x6 transmitted
#define ICUBCANPROTO_POL_AS_CMD_SET_TXMODE 0x7 // set the calibration offset
#define ICUBCANPROTO_POL_AS_CMD_SET_CANDATARATE 0x8 // set continuous/on demand transmission mode
#define ICUBCANPROTO_POL_AS_CMD_SAVE2EE 0x9 // set board CAN speed in milliseconds minimum, datarate 210ms
#define ICUBCANPROTO_POL_AS_CMD_GET_MATRIX_RC 0xA // save Config to EE
#define ICUBCANPROTO_POL_AS_CMD_GET_CH_DAC 0xB // Get TF trasformation matrix
#define ICUBCANPROTO_POL_AS_CMD_GET_CH_ADC 0xC // Get DAC for channel x
#define ICUBCANPROTO_POL_AS_CMD_FILTER_EN 0xD // Get ADC for channel x
#define ICUBCANPROTO_POL_AS_CMD_MUX_EN 0xE // ENABLE/DISABLES FILTER
#define ICUBCANPROTO_POL_AS_CMD_MUX_NUM 0xF // ENABLE/DISABLES MUX
#define ICUBCANPROTO_POL_AS_CMD_SET_RESOLUTION 0x10 //set data resolution
#define ICUBCANPROTO_POL_AS_CMD_SET_MATRIX_G 0x11 //set matrix gain
#define ICUBCANPROTO_POL_AS_CMD_GET_MATRIX_G 0x12 //get matrix gain
#define ICUBCANPROTO_POL_AS_CMD_SET_CALIB_TARE 0x13 //set/reset calibration
#define ICUBCANPROTO_POL_AS_CMD_GET_CALIB_TARE 0x14 //get calibration tare
#define ICUBCANPROTO_POL_AS_CMD_SET_CURR_TARE 0x15 //set/reset current tare
#define ICUBCANPROTO_POL_AS_CMD_GET_CURR_TARE 0x16 //get current tare
#define ICUBCANPROTO_POL_AS_CMD_SET_FULL_SCALES 0x17 //set/reset current tare
#define ICUBCANPROTO_POL_AS_CMD_GET_FULL_SCALES 0x18 //get current tare
#define ICUBCANPROTO_POL_AS_CMD_SET_SERIAL_NO 0x19 //set/reset current tare
#define ICUBCANPROTO_POL_AS_CMD_GET_SERIAL_NO 0x1A //get current tare
#define ICUBCANPROTO_POL_AS_CMD_GET_EEPROM_STATUS 0x1B //get eeprom status (saved/not saved)
#define ICUBCANPROTO_POL_AS_CMD_GET_FW_VERSION 0x1C //get fw version and check can protocol
#define ICUBCANPROTO_POL_AS_CMD_SET_BOARD_ADX 0x32 // Set board CAN address

/*****
/
// command messages of class 3: ICUBCANPROTO_CLASS_PERIODIC_ANALOGSENSOR
/*****
#define ICUBCANPROTO_PER_AS_MSG_FORCE_VECTOR 0xA // Transmit Torque values t1 t1 t2 t2 t3 t3
#define ICUBCANPROTO_PER_AS_MSG_TORQUE_VECTOR 0xB // Transmit Force values f1 f1 f2 f2 f3 f3
#define ICUBCANPROTO_PER_AS_MSG_HES0T06 0xC //hall effect sensors from 0 to 6 *8bits
#define ICUBCANPROTO_PER_AS_MSG_HES7T014 0xD //hall effect sensors from 7 to 14 *8bits

```






ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# Motor control firmware

Firmware main loop:



- Written in C
- Freescale Codewarrior crosscompiler for Motorola 56f807 microcontroller
- Source code available:
  - A library (Hardware Abstraction Layer):  
<https://svn.code.sf.net/p/robotcub/code/trunk/iCub/firmware/libDsp56f807>
  - The controller application:  
<https://svn.code.sf.net/p/robotcub/code/trunk/iCub/firmware/motorControllerDsp56f807>



ISTITUTO ITALIANO  
DI TECNOLOGIA

CFW2CAN0: Head and Torso

#### Head

boardLabel	canDeviceNum	boardId	firmware
0B0	-> 0 (cfw2can)	1	2BLLDC.1.62.out.S
0B1	-> 0 (cfw2can)	2 (3)	4DC.2.15.out.S

#### Torso

boardLabel	canDeviceNum	boardId	firmware
0B3	-> 0 (cfw2can)	6	2BLL.2.52.out.S
0B4	-> 0 (cfw2can)	5	2BLL.2.54.out.S
6SG (optional)	-> 0 (cfw2can)	14	6sg.hex

#### CFW2CAN1: Left arm

boardLabel	canDeviceNum	boardId	firmware
1B0	-> 1 (cfw2can)	1	2BLL.2.50.out.S
1B1	-> 1 (cfw2can)	2	2BLL.2.57.out.S
1B2	-> 1 (cfw2)	3 (4)	4DC.2.19.out.S
virtual FT joint sensor (shoulder)	-> 1 (cfw2can)	12	---
virtual FT joint sensor (wrist)	-> 1 (cfw2can)	11	---
Strain	-> 1 (cfw2can)	13	strain.hex
6SG Shoulder (optional)	-> 1 (cfw2can)	9	6sg.hex

#### CFW2CAN5: Left hand

boardLabel	canDeviceNum	boardId	firmware
1B3	-> 5 (cfw2can)	5 (6)	4DC.2.28.out.S
1B4	-> 5 (cfw2can)	7 (8)	4DC.2.30.out.S
MAIS	-> 5 (cfw2can)	14	mais.hex

#### CFW2CAN2: Right arm

boardLabel	canDeviceNum	boardId	firmware
2B0	-> 2 (cfw2can)	1	2BLL.2.50.out.S
2B1	-> 2 (cfw2can)	2	2BLL.2.57.out.S
2B2	-> 2 (cfw2can)	3 (4)	4DC.2.19.out.S
virtual FT joint sensor (shoulder)	-> 2 (cfw2can)	12	---
virtual FT joint sensor (wrist)	-> 2 (cfw2can)	11	---
Strain	-> 2 (cfw2can)	13	strain.hex
6SG Shoulder (optional)	-> 1 (cfw2can)	9	6sg.hex

#### CFW2CAN6: Right hand

boardLabel	canDeviceNum	boardId	firmware
2B3	-> 6 (cfw2can)	5 (6)	4DC.2.28.out.S
2B4	-> 6 (cfw2can)	7 (8)	4DC.2.30.out.S
MAIS	-> 6 (cfw2can)	14	mais.hex

#### CFW2CAN3: left leg

boardLabel	canDeviceNum	boardId	firmware
3B5	-> 3 (cfw2can)	5	2BLL.2.51.out.S
3B6	-> 3 (cfw2can)	6	2BLL.2.51.out.S
3B7	-> 3 (cfw2can)	7	2BLL.2.51.out.S
virtual FT joint sensor	-> 3 (cfw2can)	12	---
Strain	-> 3 (cfw2can)	13	strain.hex
6SG Upper Leg (optional)	-> 3 (cfw2can)	1	6sg.hex
6SG Lower Leg (optional)	-> 3 (cfw2can)	2	6sg.hex

#### CFW2CAN4: right leg

boardLabel	canDeviceNum	boardId	firmware
3B8	-> 4 (cfw2can)	8	2BLL.2.51.out.S
3B9	-> 4 (cfw2can)	9	2BLL.2.51.out.S
3B10	-> 4 (cfw2can)	10	2BLL.2.51.out.S
virtual FT joint sensor	-> 4 (cfw2can)	11	---
Strain	-> 4 (cfw2can)	14	strain.hex
6SG Upper Leg (optional)	-> 4 (cfw2can)	1	6sg.hex
6SG Lower Leg (optional)	-> 4 (cfw2can)	2	6sg.hex

#### CFW2CAN7: Skin Left Arm

boardLabel	canDeviceNum	boardId	firmware
1B7 (HAND)	-> 7 (cfw2can)	14	skin.hex
1B8 (LEFT LOWER FOREARM)	-> 7 (cfw2can)	12	skin.hex
1B9 (LEFT UPPER FOREARM)	-> 7 (cfw2can)	13	skin.hex
1B10 (LEFT UPPER EXTERNAL)	-> 7 (cfw2can)	10	skin.hex
1B11 (LEFT UPPER BOTTOM)	-> 7 (cfw2can)	11	skin.hex
1B12 (LEFT UPPER INTERNAL)	-> 7 (cfw2can)	9	skin.hex
1B13 (LEFT LOWER UPPERARM)	-> 7 (cfw2can)	8	skin.hex

#### CFW2CAN8: Skin Right Arm

boardLabel	canDeviceNum	boardId	firmware
2B7 (HAND)	-> 8 (cfw2can)	14	skin.hex
2B8 (LEFT LOWER FOREARM)	-> 8 (cfw2can)	12	skin.hex
2B9 (LEFT UPPER FOREARM)	-> 8 (cfw2can)	13	skin.hex
2B10 (RIGHT UPPER EXTERNAL)	-> 8 (cfw2can)	10	skin.hex
2B11 (RIGHT UPPER BOTTOM)	-> 8 (cfw2can)	11	skin.hex
2B12 (RIGHT UPPER INTERNAL)	-> 8 (cfw2can)	9	skin.hex
2B13 (RIGHT LOWER UPPERARM)	-> 8 (cfw2can)	8	skin.hex

#### CFW2CAN9: Skin Torso

boardLabel	canDeviceNum	boardId	firmware
0B7	-> 9 (cfw2can)	7	skin.hex
0B8	-> 9 (cfw2can)	8	skin.hex
0B9	-> 9 (cfw2can)	9	skin.hex
0B10	-> 9 (cfw2can)	10	skin.hex

More info:

<http://wiki.icub.org/wiki/>

[Can addresses and associated firmware](#)

<http://wiki.icub.org/wiki/Firmware>

User has to update fw regularly from the repository!

<https://svn.code.sf.net/p/robotcub/code/trunk/iCub/firmware/build>

Robot Interface:

- asks for the fw version to the boards
- checks if the fw use the same CAN protocol
  - CAN protocol version is increased when new features are implemented
  - If CAN protocol version is not compatible (too old), a fw update is required (robot Interface will terminate)






ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# iCub Firmware versions

## Why many firmware versions?

- Different type of motors
  - Brushless on major joints: arms, legs, torso
  - DC motors on small joints: eyes, fingers
- Different type of sensors (absolute magnetic/optical encoders, ability to perform force control using torque data)
- Joint couplings. E.g.
  - Firmware 1.51 (legs) implement a 1:1 coupling (one joint controlled by one motor)
  - Firmware 1.52 (waist) implements a 2:2 differential coupling
  - Firmware 1.50-1.57 (shoulder) implements a 3:3 differential coupling



Almost every joint has different, customized controller application -> many different firmware types



ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# iCub configuration

Example: icub-main\app\robots\iCubGenova01\icub\_all.xml

```
<?xml version="1.0" encoding="UTF-8" ?>
<robot name="icub">
  <!-- cartesian -->
  <devices file="cartesian/left_arm_cartesian.xml" />
  <devices file="cartesian/right_arm_cartesian.xml" />

  <!-- motor controllers -->
  <devices file="wrappers/motorControl/left_arm_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/right_arm_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/left_leg_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/right_leg_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/head_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/torso_mc_wrapper.xml" />
  <devices file="hardware/motorControl/icub_left_arm.xml" />
  <devices file="hardware/motorControl/icub_left_hand.xml" />
  <devices file="hardware/motorControl/icub_right_arm.xml" />
  <devices file="hardware/motorControl/icub_right_hand.xml" />
  <devices file="hardware/motorControl/icub_left_leg.xml" />
  <devices file="hardware/motorControl/icub_right_leg.xml" />
  <devices file="hardware/motorControl/icub_head.xml" />
  <devices file="hardware/motorControl/icub_torso.xml" />

  <!-- VIRTUAL ANALOG SENSORS -->
  <devices file="wrappers/VFT/left_arm_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/left_leg_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/right_arm_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/right_leg_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/torso_VFT_wrapper.xml" />
  <devices file="hardware/VFT/left_arm_virtual_strain.xml" />
  <devices file="hardware/VFT/left_leg_virtual_strain.xml" />
  <devices file="hardware/VFT/right_arm_virtual_strain.xml" />
  <devices file="hardware/VFT/right_leg_virtual_strain.xml" />
  <devices file="hardware/VFT/torso_virtual_strain.xml" />

  <!-- REAL ANALOG SENSORS -->
  <devices file="wrappers/FT/left_arm_FT_wrapper.xml" />
  <devices file="wrappers/FT/left_leg_FT_wrapper.xml" />
  <devices file="wrappers/FT/left_foot_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_arm_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_leg_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_foot_FT_wrapper.xml" />
  <devices file="wrappers/MAIS/left_hand_mais_wrapper.xml" />
  <devices file="wrappers/MAIS/right_hand_mais_wrapper.xml" />
  <devices file="hardware/FT/left_arm_strain.xml" />
  <devices file="hardware/FT/left_foot_strain.xml" />
  <devices file="hardware/FT/right_arm_strain.xml" />
  <devices file="hardware/FT/right_leg_strain.xml" />
  <devices file="hardware/FT/right_foot_strain.xml" />
  <devices file="hardware/MAIS/left_hand_mais.xml" />
  <devices file="hardware/MAIS/right_hand_mais.xml" />

  <!-- SKIN -->
  <devices file="wrappers/skin/left_arm_skin_wrapper.xml" />
  <devices file="wrappers/skin/right_arm_skin_wrapper.xml" />
  <devices file="wrappers/skin/torso_skin_wrapper.xml" />
  <devices file="hardware/skin/left_arm.xml" />
  <devices file="hardware/skin/right_arm.xml" />
  <devices file="hardware/skin/torso.xml" />

  <!-- CALIBRATORS -->
  <devices file="calibrators/head_calib.xml" />
  <devices file="calibrators/torso_calib.xml" />
  <devices file="calibrators/right_leg_calib.xml" />
  <devices file="calibrators/left_leg_calib.xml" />
  <devices file="calibrators/left_arm_calib.xml" />
  <devices file="calibrators/right_arm_calib.xml" />
  <devices file="calibrators/left_hand_calib.xml" />
  <devices file="calibrators/right_hand_calib.xml" />
</robot>
```





ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# iCub configuration

Example: icub-main\app\robots\iCubGenova01\icub\_all.xml

```
<?xml version="1.0" encoding="UTF-8" ?>
<robot name="iCub">
  <!-- cartesian -->
  <devices file="cartesian/left_arm_cartesian.xml" />
  <devices file="cartesian/right_arm_cartesian.xml" />

  <!-- motor controllers -->
  <devices file="wrappers/motorControl/left_arm_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/right_arm_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/left_leg_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/right_leg_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/head_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/torso_mc_wrapper.xml" />

  CAN1 --> <devices file="hardware/motorControl/icub_left_arm.xml" />
  CAN5 --> <devices file="hardware/motorControl/icub_left_hand.xml" />
  CAN2 --> <devices file="hardware/motorControl/icub_right_arm.xml" />
  CAN6 --> <devices file="hardware/motorControl/icub_right_hand.xml" />
  CAN3 --> <devices file="hardware/motorControl/icub_left_leg.xml" />
  CAN4 --> <devices file="hardware/motorControl/icub_right_leg.xml" />
  CAN0 --> <devices file="hardware/motorControl/icub_head.xml" />
  CAN0 --> <devices file="hardware/motorControl/icub_torso.xml" />

  <!-- VIRTUAL ANALOG SENSORS -->
  <devices file="wrappers/VFT/left_arm_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/left_leg_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/right_arm_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/right_leg_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/torso_VFT_wrapper.xml" />

  CAN1 --> <devices file="hardware/VFT/left_arm_virtual_strain.xml" />
  CAN3 --> <devices file="hardware/VFT/left_leg_virtual_strain.xml" />
  CAN2 --> <devices file="hardware/VFT/right_arm_virtual_strain.xml" />
  CAN4 --> <devices file="hardware/VFT/right_leg_virtual_strain.xml" />
  CAN0 --> <devices file="hardware/VFT/torso_virtual_strain.xml" />

  <!-- REAL ANALOG SENSORS -->
  <devices file="wrappers/FT/left_arm_FT_wrapper.xml" />
  <devices file="wrappers/FT/left_leg_FT_wrapper.xml" />
  <devices file="wrappers/FT/left_foot_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_arm_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_leg_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_foot_FT_wrapper.xml" />
  <devices file="wrappers/MAIS/left_hand_mais_wrapper.xml" />
  <devices file="wrappers/MAIS/right_hand_mais_wrapper.xml" />
  <devices file="hardware/FT/left_arm_strain.xml" /> <!-- CAN1
  <devices file="hardware/FT/left_leg_strain.xml" /> <!-- CAN3
  <devices file="hardware/FT/left_foot_strain.xml" /> <!-- CAN3
  <devices file="hardware/FT/right_arm_strain.xml" /> <!-- CAN2
  <devices file="hardware/FT/right_leg_strain.xml" /> <!-- CAN4
  <devices file="hardware/FT/right_foot_strain.xml" /> <!-- CAN4
  <devices file="hardware/MAIS/left_hand_mais.xml" /> <!-- CAN5
  <devices file="hardware/MAIS/right_hand_mais.xml" /> <!-- CAN6

  <!-- SKIN -->
  <devices file="wrappers/skin/left_arm_skin_wrapper.xml" />
  <devices file="wrappers/skin/right_arm_skin_wrapper.xml" />
  <devices file="wrappers/skin/torso_skin_wrapper.xml" />
  <devices file="hardware/skin/left_arm.xml" />
  <devices file="hardware/skin/right_arm.xml" />
  <devices file="hardware/skin/torso.xml" />

  <!-- CALIBRATORS -->
  <devices file="calibrators/head_calib.xml" />
  <devices file="calibrators/torso_calib.xml" />
  <devices file="calibrators/right_leg_calib.xml" />
  <devices file="calibrators/left_leg_calib.xml" />
  <devices file="calibrators/left_arm_calib.xml" />
  <devices file="calibrators/right_arm_calib.xml" />
  <devices file="calibrators/left_hand_calib.xml" />
  <devices file="calibrators/right_hand_calib.xml" />
</robot>
```



ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# iCub configuration

Example: icub-main\app\robots\iCubGenova01\icub\_all.xml

```
<?xml version="1.0" encoding="UTF-8" ?>
<robot name="icub">
  <!-- cartesian -->
  <devices file="cartesian/left_arm_cartesian.xml" />
  <devices file="cartesian/right_arm_cartesian.xml" />

  <!-- motor controllers -->
  <devices file="wrappers/motorControl/left_arm_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/right_arm_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/left_leg_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/right_leg_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/head_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/torso_mc_wrapper.xml" />
  <devices file="hardware/motorControl/icub_left_arm.xml" />
  <devices file="hardware/motorControl/icub_left_hand.xml" />
  <devices file="hardware/motorControl/icub_right_arm.xml" />
  <devices file="hardware/motorControl/icub_right_hand.xml" />
  <devices file="hardware/motorControl/icub_left_leg.xml" />
  <devices file="hardware/motorControl/icub_right_leg.xml" />
  <devices file="hardware/motorControl/icub_head.xml" />
  <devices file="hardware/motorControl/icub_torso.xml" />

  <!-- VIRTUAL ANALOG SENSORS -->
  <devices file="wrappers/VFT/left_arm_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/left_leg_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/right_arm_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/right_leg_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/torso_VFT_wrapper.xml" />
  <devices file="hardware/VFT/left_arm_virtual_strain.xml" />
  <devices file="hardware/VFT/left_leg_virtual_strain.xml" />
  <devices file="hardware/VFT/right_arm_virtual_strain.xml" />
  <devices file="hardware/VFT/right_leg_virtual_strain.xml" />
  <devices file="hardware/VFT/torso_virtual_strain.xml" />

  <!-- REAL ANALOG SENSORS -->
  <devices file="wrappers/FT/left_arm_FT_wrapper.xml" />
  <devices file="wrappers/FT/left_leg_FT_wrapper.xml" />
  <devices file="wrappers/FT/left_foot_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_arm_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_leg_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_foot_FT_wrapper.xml" />
  <devices file="wrappers/MAIS/left_hand_mais_wrapper.xml" />
  <devices file="wrappers/MAIS/right_hand_mais_wrapper.xml" />
  <devices file="hardware/FT/left_arm_strain.xml" />
  <devices file="hardware/FT/left_leg_strain.xml" />
  <devices file="hardware/FT/left_foot_strain.xml" />
  <devices file="hardware/FT/right_arm_strain.xml" />
  <devices file="hardware/FT/right_leg_strain.xml" />
  <devices file="hardware/FT/right_foot_strain.xml" />
  <devices file="hardware/MAIS/left_hand_mais.xml" />
  <devices file="hardware/MAIS/right_hand_mais.xml" />

  <!-- SKIN -->
  <devices file="wrappers/skin/left_arm_skin_wrapper.xml" />
  <devices file="wrappers/skin/right_arm_skin_wrapper.xml" />
  <devices file="wrappers/skin/torso_skin_wrapper.xml" />
  <devices file="hardware/skin/left_arm.xml" />
  <devices file="hardware/skin/right_arm.xml" />
  <devices file="hardware/skin/torso.xml" />

  <!-- CALIBRATORS -->
  <devices file="calibrators/head_calib.xml" />
  <devices file="calibrators/torso_calib.xml" />
  <devices file="calibrators/right_leg_calib.xml" />
  <devices file="calibrators/left_leg_calib.xml" />
  <devices file="calibrators/left_arm_calib.xml" />
  <devices file="calibrators/right_arm_calib.xml" />
  <devices file="calibrators/left_hand_calib.xml" />
  <devices file="calibrators/right_hand_calib.xml" />
</robot>
```



ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# iCub configuration

Example: icub-main\app\robots\iCubGenova01\icub\_all.xml

```
<?xml version="1.0" encoding="UTF-8" ?>
<robot name="icub">
  <!-- cartesian -->
  <devices file="cartesian/left_arm_cartesian.xml" />
  <devices file="cartesian/right_arm_cartesian.xml" />

  <!-- motor controllers -->
  <devices file="wrappers/motorControl/left_arm_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/right_arm_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/left_leg_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/right_leg_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/head_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/torso_mc_wrapper.xml" />
  <devices file="hardware/motorControl/icub_left_arm.xml" />
  <devices file="hardware/motorControl/icub_left_hand.xml" />
  <devices file="hardware/motorControl/icub_right_arm.xml" />
  <devices file="hardware/motorControl/icub_right_hand.xml" />
  <devices file="hardware/motorControl/icub_left_leg.xml" />
  <devices file="hardware/motorControl/icub_right_leg.xml" />
  <devices file="hardware/motorControl/icub_head.xml" />
  <devices file="hardware/motorControl/icub_torso.xml" />

  <!-- VIRTUAL ANALOG SENSORS -->
  <devices file="wrappers/VFT/left_arm_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/left_leg_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/right_arm_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/right_leg_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/torso_VFT_wrapper.xml" />
  <devices file="hardware/VFT/left_arm_virtual_strain.xml" />
  <devices file="hardware/VFT/left_leg_virtual_strain.xml" />
  <devices file="hardware/VFT/right_arm_virtual_strain.xml" />
  <devices file="hardware/VFT/right_leg_virtual_strain.xml" />
  <devices file="hardware/VFT/torso_virtual_strain.xml" />

  <!-- REAL ANALOG SENSORS -->
  <devices file="wrappers/FT/left_arm_FT_wrapper.xml" />
  <devices file="wrappers/FT/left_leg_FT_wrapper.xml" />
  <devices file="wrappers/FT/left_foot_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_arm_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_leg_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_foot_FT_wrapper.xml" />
  <devices file="wrappers/MAIS/left_hand_mais_wrapper.xml" />
  <devices file="wrappers/MAIS/right_hand_mais_wrapper.xml" />
  <devices file="hardware/FT/left_arm_strain.xml" />
  <devices file="hardware/FT/left_foot_strain.xml" />
  <devices file="hardware/FT/right_arm_strain.xml" />
  <devices file="hardware/FT/right_leg_strain.xml" />
  <devices file="hardware/FT/right_foot_strain.xml" />
  <devices file="hardware/MAIS/left_hand_mais.xml" />
  <devices file="hardware/MAIS/right_hand_mais.xml" />

  <!-- SKIN -->
  <devices file="wrappers/skin/left_arm_skin_wrapper.xml" />
  <devices file="wrappers/skin/right_arm_skin_wrapper.xml" />
  <devices file="wrappers/skin/torso_skin_wrapper.xml" />
  <devices file="hardware/skin/left_arm.xml" />
  <devices file="hardware/skin/right_arm.xml" />
  <devices file="hardware/skin/torso.xml" />

  <!-- CALIBRATORS -->
  <devices file="calibrators/head_calib.xml" />
  <devices file="calibrators/torso_calib.xml" />
  <devices file="calibrators/right_leg_calib.xml" />
  <devices file="calibrators/left_leg_calib.xml" />
  <devices file="calibrators/left_arm_calib.xml" />
  <devices file="calibrators/right_arm_calib.xml" />
  <devices file="calibrators/left_hand_calib.xml" />
  <devices file="calibrators/right_hand_calib.xml" />
</robot>
```



ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# iCub configuration

Example: icub-main\app\robots\iCubGenova01\icub\_all.xml

```
<?xml version="1.0" encoding="UTF-8" ?>
<robot name="icub">
  <!-- cartesian -->
  <devices file="cartesian/left_arm_cartesian.xml" />
  <devices file="cartesian/right_arm_cartesian.xml" />

  <!-- motor controllers -->
  <devices file="wrappers/motorControl/left_arm_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/right_arm_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/left_leg_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/right_leg_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/head_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/torso_mc_wrapper.xml" />
  <devices file="hardware/motorControl/icub_left_arm.xml" />
  <devices file="hardware/motorControl/icub_left_hand.xml" />
  <devices file="hardware/motorControl/icub_right_arm.xml" />
  <devices file="hardware/motorControl/icub_right_hand.xml" />
  <devices file="hardware/motorControl/icub_left_leg.xml" />
  <devices file="hardware/motorControl/icub_right_leg.xml" />
  <devices file="hardware/motorControl/icub_head.xml" />
  <devices file="hardware/motorControl/icub_torso.xml" />

  <!-- VIRTUAL ANALOG SENSORS -->
  <devices file="wrappers/VFT/left_arm_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/left_leg_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/right_arm_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/right_leg_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/torso_VFT_wrapper.xml" />
  <devices file="hardware/VFT/left_arm_virtual_strain.xml" />
  <devices file="hardware/VFT/left_leg_virtual_strain.xml" />
  <devices file="hardware/VFT/right_arm_virtual_strain.xml" />
  <devices file="hardware/VFT/right_leg_virtual_strain.xml" />
  <devices file="hardware/VFT/torso_virtual_strain.xml" />

  <!-- REAL ANALOG SENSORS -->
  <devices file="wrappers/FT/left_arm_FT_wrapper.xml" />
  <devices file="wrappers/FT/left_leg_FT_wrapper.xml" />
  <devices file="wrappers/FT/left_foot_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_arm_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_leg_FT_wrapper.xml" />
  <devices file="wrappers/FT/right_foot_FT_wrapper.xml" />
  <devices file="wrappers/MAIS/left_hand_mais_wrapper.xml" />
  <devices file="wrappers/MAIS/right_hand_mais_wrapper.xml" />
  <devices file="hardware/FT/left_arm_strain.xml" />
  <devices file="hardware/FT/left_leg_strain.xml" />
  <devices file="hardware/FT/left_foot_strain.xml" />
  <devices file="hardware/FT/right_arm_strain.xml" />
  <devices file="hardware/FT/right_leg_strain.xml" />
  <devices file="hardware/FT/right_foot_strain.xml" />
  <devices file="hardware/MAIS/left_hand_mais.xml" />
  <devices file="hardware/MAIS/right_hand_mais.xml" />

  <!-- SKIN -->
  <devices file="wrappers/skin/left_arm_skin_wrapper.xml" />
  <devices file="wrappers/skin/right_arm_skin_wrapper.xml" />
  <devices file="wrappers/skin/torso_skin_wrapper.xml" />
  <devices file="hardware/skin/left_arm.xml" />
  <devices file="hardware/skin/right_arm.xml" />
  <devices file="hardware/skin/torso.xml" />

  <!-- CALIBRATORS -->
  <devices file="calibrators/head_calib.xml" />
  <devices file="calibrators/torso_calib.xml" />
  <devices file="calibrators/right_leg_calib.xml" />
  <devices file="calibrators/left_leg_calib.xml" />
  <devices file="calibrators/left_arm_calib.xml" />
  <devices file="calibrators/right_arm_calib.xml" />
  <devices file="calibrators/left_hand_calib.xml" />
  <devices file="calibrators/right_hand_calib.xml" />
</robot>
```





ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# iCub configuration

Example: icub-main\app\robots\iCubGenova01\icub\_all.xml

## Disabling a part (left arm) ...

```
<?xml version="1.0" encoding="UTF-8" ?>
<robot name="icub">
  <!-- cartesian -->
  <devices file="cartesian/left_arm_cartesian.xml" />
  <devices file="cartesian/right_arm_cartesian.xml" />

  <!-- motor controllers -->
  <devices file="wrappers/motorControl/left_arm_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/right_arm_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/left_leg_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/right_leg_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/head_mc_wrapper.xml" />
  <devices file="wrappers/motorControl/torso_mc_wrapper.xml" />
  <devices file="hardware/motorControl/icub_left_arm.xml" />
  <devices file="hardware/motorControl/icub_left_hand.xml" />
  <devices file="hardware/motorControl/icub_right_arm.xml" />
  <devices file="hardware/motorControl/icub_right_hand.xml" />
  <devices file="hardware/motorControl/icub_left_leg.xml" />
  <devices file="hardware/motorControl/icub_right_leg.xml" />
  <devices file="hardware/motorControl/icub_head.xml" />
  <devices file="hardware/motorControl/icub_torso.xml" />

  <!-- VIRTUAL ANALOG SENSORS -->
  <devices file="wrappers/VFT/left_arm_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/left_leg_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/right_arm_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/right_leg_VFT_wrapper.xml" />
  <devices file="wrappers/VFT/torso_VFT_wrapper.xml" />
  <devices file="hardware/VFT/left_arm_virtual_strain.xml" />
  <devices file="hardware/VFT/left_leg_virtual_strain.xml" />
  <devices file="hardware/VFT/right_arm_virtual_strain.xml" />
  <devices file="hardware/VFT/right_leg_virtual_strain.xml" />
  <devices file="hardware/VFT/torso_virtual_strain.xml" />
```

```
<!-- REAL ANALOG SENSORS -->
<devices file="wrappers/FT/left_arm_FT_wrapper.xml" />
<devices file="wrappers/FT/left_leg_FT_wrapper.xml" />
<devices file="wrappers/FT/left_foot_FT_wrapper.xml" />
<devices file="wrappers/FT/right_arm_FT_wrapper.xml" />
<devices file="wrappers/FT/right_leg_FT_wrapper.xml" />
<devices file="wrappers/FT/right_foot_FT_wrapper.xml" />
<devices file="wrappers/MAIS/left_hand_mais_wrapper.xml" />
<devices file="wrappers/MAIS/right_hand_mais_wrapper.xml" />
<devices file="hardware/FT/left_arm_strain.xml" />
<devices file="hardware/FT/left_foot_strain.xml" />
<devices file="hardware/FT/right_arm_strain.xml" />
<devices file="hardware/FT/right_leg_strain.xml" />
<devices file="hardware/FT/right_foot_strain.xml" />
<devices file="hardware/MAIS/left_hand_mais.xml" />
<devices file="hardware/MAIS/right_hand_mais.xml" />

<!-- SKIN -->
<devices file="wrappers/skin/left_arm_skin_wrapper.xml" />
<devices file="wrappers/skin/right_arm_skin_wrapper.xml" />
<devices file="wrappers/skin/torso_skin_wrapper.xml" />
<devices file="hardware/skin/left_arm.xml" />
<devices file="hardware/skin/right_arm.xml" />
<devices file="hardware/skin/torso.xml" />

<!-- CALIBRATORS -->
<devices file="calibrators/head_calib.xml" />
<devices file="calibrators/torso_calib.xml" />
<devices file="calibrators/right_leg_calib.xml" />
<devices file="calibrators/left_leg_calib.xml" />
<devices file="calibrators/left_arm_calib.xml" />
<devices file="calibrators/right_arm_calib.xml" />
<devices file="calibrators/left_hand_calib.xml" />
<devices file="calibrators/right_hand_calib.xml" />
</robot>
```



ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# iCub configuration

Example: icub-main\app\robots\iCubGenova01\wrappers\motorControl\left\_arm\_mc\_wrapper.xml

```
<?xml version="1.0" encoding="UTF-8" ?>
<devices>
  <device name="left_arm_mc_wrapper" type="controlboardwrapper2">
    <param name="threadrate"> 10 </param>
    <paramlist name="networks">
      <elem name="left_arm_joints"> 0 7 0 7 </elem>
      <elem name="left_hand_joints"> 8 15 0 7 </elem>
    </paramlist>

    <param name="period"> 10 </param>
    <param name="name"> icub/left_arm </param>
    <param name="ports"> left_arm </param>
    <param name="joints"> 16 </param>

    <action phase="startup" level="5" type="attach">
      <paramlist name="networks">
        <elem name="left_arm_joints"> left_arm_mc </elem>
        <elem name="left_hand_joints"> left_hand_mc </elem>
      </paramlist>
    </action>

    <action phase="shutdown" level="5" type="detach" />
  </device>
</devices>
```

- User typically does not need to edit files in the wrapper folder
- User may tune the configuration parameters of the robot editing files contained in the hardware folder



ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# iCub configuration

Example: icub-main\app\robots\iCubGenova01\wrappers\motorControl\left\_arm\_mc\_wrapper.xml

```
<?xml version="1.0" encoding="UTF-8" ?>
<devices>
  <device name="left_arm_mc_wrapper" type="controlboardwrapper2">
    <param name="threadrate"> 10 </param>
    <paramlist name="networks">
      <elem name="left_arm_joints"> 0 7 0 7 </elem>
      <elem name="left_hand_joints"> 8 15 0 7 </elem>
    </paramlist>

    <param name="period"> 10 </param>
    <param name="name"> icub/left_arm </param>
    <param name="ports"> left_arm </param>
    <param name="joints"> 16 </param>

    <action phase="startup" level="5" type="attach">
      <paramlist name="networks">
        <elem name="left_arm_joints"> left_arm_mc </elem>
        <elem name="left_hand_joints"> left_hand_mc </elem>
      </paramlist>
    </action>

    <action phase="shutdown" level="5" type="detach" />
  </device>
</devices>
```

- User typically does not need to edit files in the wrapper folder (with the only exception of the period param)
- User may tune the configuration parameters of the robot editing files contained in the hardware folder



ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# iCub configuration

Example: icub-main\app\robots\iCubGenova01\hardware\motorControl\left\_arm\_mc.xml

```
<?xml version="1.0" encoding="UTF-8" ?>
<devices>
  <device name="left_arm_mc" type="canmotioncontrol">
    <params file="general.xml" />

    <group name="CAN">
      <param name="canbusdevice"> sharedcan </param>
      <param name="physDevice"> cfw2can </param>
      <param name="CanAddresses"> 1 2 3 4 </param>
      <param name="CanDeviceNum"> 1 </param>
      <param name="NetworkId"> LEFT_ARM </param>
      <param name="CanMyAddress"> 0 10 </param>
      <param name="CanPollingInterval"> </param>
      <param name="CanTimeout"> 500 </param>
      <param name="CanTxTimeout"> 500 </param>
      <param name="CanRxTimeout"> 500 </param>
      <param name="broadcast_pos"> 1 </param>
      <param name="broadcast_pid"> 1 1 1 0 0 0 0 </param>
      <param name="broadcast_fault"> 1 1 1 1 1 1 1 </param>
      <param name="broadcast_current"> 0 0 0 0 0 0 0 </param>
      <param name="broadcast_canprint"> 1 1 1 1 1 1 1 </param>
      <param name="broadcast_vel_acc"> 0 0 0 0 0 0 0 </param>
    </group>

    <group name="GENERAL"> 8 </param>
    <param name="Joints">
      <param name="AxisMap"> 0 1 2 3 4 5 6 7 </param>
      <param name="Encoder"> -11.375 -11.375 -11.375 -11.375 -706.67 -978.46 -978.46 -2.83333 </param>
      <param name="Zeros"> -185.5 -333 9.257819 -189 90 -24 -45 -554.118 </param>
      <param name="TorqueId"> 0x0C 0x0C 0x0C 0x0C 0x0C 0 0 0 </param>
      <param name="TorqueChan"> 0 1 2 3 4 0 0 0 </param>
      <param name="TorqueMax"> 8 8 8 8 2 2 2 2 </param>
    </group>

    <group name="VELOCITY"> 8 8 8 8 8 8 8 </param>
    <param name="Shifts">
      <param name="Timeout"> 100 100 100 100 100 100 100 100 </param>
    </group>

    <group name="LIMITS"> -95.5 0 -30 15 -90 -80 -20 0 </param>
    <param name="Min">
      <param name="Max"> 10 160.8 75 106 90 25 25 60 </param>
      <param name="Currents"> 7000 7000 7000 7000 500 800 800 800 </param>
    </group>

    <group name="POS_PIDS"> 32000 32000 10000 32000 200 100 100 200 </param>
    <param name="kp">
      <param name="kd"> 50 50 0 20 1000 100 100 200 </param>
      <param name="ki"> 60 60 10 60 1 2 2 1 </param>
      <param name="maxPwm"> 800 800 800 800 1333 1333 1333 1333 </param>
      <param name="maxInt"> 800 800 800 800 1333 1333 1333 1333 </param>
      <param name="shift"> 13 13 13 13 6 6 6 4 </param>
      <param name="ko"> 0 0 0 0 0 0 0 0 </param>
      <param name="stictionUp"> 0 0 0 0 0 0 0 0 </param>
      <param name="stictionDwn"> 0 0 0 0 0 0 0 0 </param>
    </group>
  </device>
</devices>
```





ISTITUTO ITALIANO  
DI TECNOLOGIA  
DI TECNOLOGIA  
ISTITUTO ITALIANO

# iCub configuration

Example: icub-main\app\robots\iCubGenova01\hardware\motorControl\left\_arm\_mc.xml

In the robot configuration files values, parameters are often expressed in hardware units (no floating point support in the firmware):

- Encoder conversion factor (from ticks to degrees):

```
<param name="Encoder"> -11.375 -11.375 -11.375 -11.375 -706.67 -978.46 -978.46 -2.83333 </param>
```

4096 (ticks per revolution) / 360 (degrees) = 11.375 (typical AEA encoder)

254400 (ticks per revolution) 360 (degrees) = 706,666 (optical encoder)

(sign depends if the motor rotates cw or ccw respect to the encoder)


- The PID gains:

```
<group name="POS_PIDS">
<param name="kp"> 32000 32000 10000 32000 200 100 100 200 </param>
<param name="kd"> 50 50 0 20 1000 100 100 200 </param>
<param name="ki"> 60 60 10 60 1 2 2 1 </param>
<param name="maxPwm"> 800 800 800 800 1333 1333 1333 1333 </param>
<param name="maxInt"> 800 800 800 800 1333 1333 1333 1333 </param>
<param name="shift"> 13 13 13 13 6 6 6 4 </param>
<param name="ko"> 0 0 0 0 0 0 0 0 </param>
<param name="stictionUp"> 0 0 0 0 0 0 0 0 </param>
<param name="stictionDwn"> 0 0 0 0 0 0 0 0 </param>
```

PWM = 1333 units correspond to the maximum supply voltage (typ: ~40v)

$$\begin{aligned} KP &= 32000 * 2^{-13} \text{ PWMs/encTick} = 0.256 \text{ PWMs/encTick} \\ &= 0.256 * 40 / 1333 \text{ V/encTick} = 0.00768 \text{ V/encTick} \\ &= 0.00768 * 4096 / 360 \text{ V/deg} = 0.0874 \text{ V/deg} \end{aligned}$$

# iCub joint torque control: an example



1. Encoders and F/T data are broadcasted by motor control boards and sensors on the CAN bus.
2. robotInterfaces dispatches the data through the network of PCs. User modules can read data using YARP interfaces.
3. The software module WholeBodyDynamics estimates iCub joint torques (using the dynamic model of the robot) and send them back to robotInterface.
4. RobotInterfaces simulates a virtual analog sensor broadcasting on the CANbus force/torque data messages (SEE virtual analog sensor wrapper .xml file)
5. The motor control board receives the virtual analog sensor data. It can now close a torque control loop at joint level.